

C# Database Workshop — ADO.NET, EF Core

This hands-on workshop guides you through connecting C# applications to SQL Server using both ADO.NET and Entity Framework Core. You'll build a console app and a minimal API that work with both a code-first and a database-first (Northwind) approach.

Part 1 — Console App (ADO.NET + EF Core)

Let's connect directly to a database and use EF Core with a code-first approach!

Step 1 – Create Project

Create a new Console project in Visual Studio 2022 (.NET 8) called **DbWorkshopConsole**.


In VS 2022 → *File* → *New* → *Project*

Choose **Console App (.NET 6 or .NET 8)** → click **Next** → finish setup

Step 2 – Add NuGet Packages

Install Entity Framework NuGet packages

Install the following NuGet packages using the Package Manager Console:



Install-Package Microsoft.EntityFrameworkCore

Install-Package Microsoft.EntityFrameworkCore.SqlServer

Install-Package Microsoft.EntityFrameworkCore.Tools

Note: Make sure you are in the folder where your C# project is when executing the above commands

(You might have to install .NET Framework for older projects in older apps but we use **EF Core** here)

Step 3 — Create your model classes

Let's say you have a Student entity:

```
public class Student
{
    public int Id { get; set; }
    public string Name { get; set; }
    public int Age { get; set; }
}
```


Step 4 — Create a DbContext

This class defines the connection and tables.

```
using Microsoft.EntityFrameworkCore;
public class SchoolContext : DbContext
{
    public DbSet<Student> Students { get; set; }

    protected override void OnConfiguring(DbContextOptionsBuilder options)
    {
        options.UseSqlServer(
            "Server=(localdb)\\MSSQLLocalDB;Database=SchoolDB;Trusted_Connection=True;");
    }
}
```

LocalDB comes with Visual Studio. You can check it in **SQL Server Object Explorer**.



LocalDB is a lightweight, developer-only edition of SQL Server that is automatically installed with Visual Studio. It's designed for **local development**, not production but it's still SQL Server Express under the hood

Step 5 — Create the database (migrations)

In **Package Manager Console**, run:

Add-Migration InitialCreate

Update-Database

- **Add-Migration** creates a migration file describing your tables.
- **Update-Database** actually creates the database.

You'll now see **SchoolDB** under **(localdb)\MSSQLLocalDB**.

Note: You may need to Refresh the databases node to see the new **SchoolDB** database

Step 6 — Use EF in code

In your **Program.cs Main()** method type:

```
using var db = new SchoolContext();

db.Students.Add(new Student { Name = "Mike", Age = 21 });
db.SaveChanges();

// Read
var list = db.Students.ToList();
foreach (var s in list)
    Console.WriteLine($"{s.Id}: {s.Name} ({s.Age})");
```

(feel free to add a few more rows to the table)

Step 7 — View your data In Visual Studio:

- Open View → SQL Server Object Explorer
- Expand (localdb)\MSSQLLocalDB → Databases → SchoolDB
- Right-click Students → View Data

You'll see your table populated.

	Id	Name	Age
▶	1	Mike	21
	2	Linda	23
*	3	Jonathan	43
	NULL	NULL	NULL

Note: To remove a student try `db.Students.Remove(new Student { Id = 3 });`

To remove the third student

Step 8 — Common variations - Using scaffolding (reverse-engineer from existing DB)

If you already have a database type the following in the NuGet Console (all on one line).

For example, I have a database called **Northwind** on **SQLExpress** server. So I type

```
Scaffold-DbContext  
"Server=.\SQLExpress;Database=Northwind;Trusted_Connection=True;TrustServerCertificate=True;" Microsoft.EntityFrameworkCore.SqlServer -OutputDir Models
```

(All on one line)

This will create a folder in your project called **Models**. Please make sure this folder exists and there are no error reported.

Using configuration file (optional)

You can also store connection strings in `appsettings.json` (for web apps) or `app.config` (for older console apps).

Just to recap, so far, you have:

- 1 Created a new C# project
- 2 Installed EF Core NuGet packages
- 3 Defined your model classes
- 4 Created a DbContext
- 5 Ran Add-Migration + Update-Database
- 6 Used EF methods (Add, Find,ToList, SaveChanges)
- 7 Viewed data in SQL Server Object Explorer

Now, let's connect to and use a database in **SQL Express** directly from **Visual Studio 2022 C# app**.


Find or create your database

Option A — Using SQL Server Management Studio (SSMS)

1. Connect to **Server name:** .\SQLEXPRESS
(or localhost\SQLEXPRESS)

Option B — Using Visual Studio (recommended for fewer screen swappint)

1. Open **View → SQL Server Object Explorer**
2. Click the “+ Add SQL Server” icon
3. Choose **Database Engine**
4. **Server name:** .\SQLEXPRESS
(or localhost\SQLEXPRESS)
5. **Authentication:** Windows Authentication
6. Trust server Certificate = True
7. No need to change anything else, just click **Connect**



Step 3 — Connection string for C#

The connection string usually looks like this:

```
"Server=.\SQLEXPRESS;Database=Northwind;Trusted_Connection=True;TrustServerCertificate=True"
```

or if using localdb (from VS default templates):

```
Server=(localdb)\MSSQLLocalDB;Database=TestDB;Trusted_Connection=True;
```

Step 4 — Access it with ADO.NET (raw)

If this code outputs “Connected!”, your connection works!

```
using System;
using System.Data.SqlClient;

class Program
{
    static void Main()
    {
        string connString = "Server=.\SQLExpress;Database=Northwind;Trusted_Connection=True; ;TrustServerCertificate=True";

        using (SqlConnection conn = new SqlConnection(connString))
        {
            conn.Open();
            Console.WriteLine("Connected!");

            string sql = "SELECT COUNT(*) FROM customers";
            using (SqlCommand cmd = new SqlCommand(sql, conn))
            {
                int count = (int)cmd.ExecuteScalar();
                Console.WriteLine($"Rows: {count}");
            }
        }
    }
}
```

To read data type:

```
static void readDataExample()
{
    string connString =
"Server=.\SQLExpress;Database=Northwind;Trusted_Connection=True; ;TrustServerCertificate=True";

    using (SqlConnection conn = new SqlConnection(connString))
    {
        conn.Open();
        Console.WriteLine("Connected!");

        string sql = "SELECT * FROM customers";
        using (SqlCommand cmd = new SqlCommand(sql, conn))
        {
            SqlDataReader reader = cmd.ExecuteReader();
            while (reader.Read())
            {
                string city = reader["City"].ToString();
                Console.WriteLine($"{reader[0]} {reader[1]} {city}");
            }
        }
    }
}
```

Note: You can use Insert or delete using code like:

```
static void part4()
{
    string connString =
"Server=.\SQLExpress;Database=Northwind;Trusted_Connection=True; ;TrustServerCertificate=True";

    using (SqlConnection conn = new SqlConnection(connString))
    {
        conn.Open();
```

```

Console.WriteLine("Connected!");

string sql = "DELETE FROM customers WHERE CustomerID='zzzzz'";
using (SqlCommand cmd = new SqlCommand(sql, conn))
{
    int rowsAffected = cmd.ExecuteNonQuery();
    if (rowsAffected > 0)
    {
        Console.WriteLine($"Number of row affected: {rowsAffected}");
    }
}
}

```

Step 5 — Access it with Entity Framework Core

Create another class called **MyDbContext**

```

public class MyDbContext : DbContext
{
    public DbSet<Customer> Customers { get; set; }

    protected override void OnConfiguring(DbContextOptionsBuilder options)
        => options.UseSqlServer(@"Server=.\SQLEXPRESS;Database=TestDB;Trusted_Connection=True");
}

```

Then run the following in NuGet console to create the tables

Add-Migration Initial

Update-Database

Step 6 — Check data visually

In Visual Studio → SQL Server Object Explorer:

- Expand .\SQLEXPRESS → Databases → TestDB → Tables
 - Right-click a table → *View Data*
-

Just to review what you've achieved: 

Task	How
Start service	Services.msc → SQL Server (SQLEXPRESS)
Create DB	SSMS or Visual Studio SQL Server Object Explorer
Connect from code	Server=.\SQLEXPRESS;Database=YourDB;Trusted_Connection=True;
Use in ADO.NET	SqlConnection, SqlCommand
Use in EF Core	options.UseSqlServer(connectionString)

Step-by-step to connect EF to your existing SQL Express database.

(We'll use **Entity Framework Core**, since you're on Visual Studio 2022.)

Step 1 — Install EF Core packages

In Visual Studio → Tools → NuGet Package Manager → Package Manager Console, run:

```
Install-Package Microsoft.EntityFrameworkCore
```

```
Install-Package Microsoft.EntityFrameworkCore.SqlServer
```

```
Install-Package Microsoft.EntityFrameworkCore.Tools
```

These let EF talk to SQL Server and create migrations.

Step 2 — Create your model classes

Let's say your database has a table Students with columns Id, Name, and Age.

Create a class to match it:

```
public class Student
{
    public int Id { get; set; } // must match the table's primary key
    public string Name { get; set; }
    public int Age { get; set; }
}
```

✿ Step 3 — Create a DbContext

This is the bridge between your code and the SQL Express database.

```
using Microsoft.EntityFrameworkCore;

public class MyDbContext : DbContext
{
    public DbSet<Student> Students { get; set; }

    protected override void OnConfiguring(DbContextOptionsBuilder options)
    {
        options.UseSqlServer(
            "Server=.\SQLExpress;Database=TestDB;Trusted_Connection=True;TrustServerCertificate=True;");
    }
}
```

Notice the connection string includes `TrustServerCertificate=True`.

You can research this attribute at another time.

Step 4 — Run EF commands (optional)

If you want EF to **create** or **update** the database schema (code-first):

Add-Migration InitialCreate

Update-Database

But if your database already exists and you just want to use it (read/write), you can skip this step or use **Database-First Scaffolding** (see Step 6).

Step 5 — Use EF in code

Example: read and write to your Students table.

```
using System;
using System.Linq;

class Program
{
    static void Main()
    {
        using var db = new MyDbContext();

        // Add a new record
        db.Students.Add(new Student { Name = "Mike", Age = 21 });
        db.SaveChanges();

        // Read all
        var list = db.Students.ToList();
        foreach (var s in list)
            Console.WriteLine($"{s.Id}: {s.Name} ({s.Age})");
    }
}
```

Run that in your console app — it will insert and list rows.

Step 6 — Reverse engineer from an existing database

If you already have tables in SQL Express and don't want to re-create them, use **scaffolding**.

In NuGet Package Manager Console:

```
Install-Package Microsoft.EntityFrameworkCore.SqlServer
```

```
Install-Package Microsoft.EntityFrameworkCore.Tools
```

Add your EF classes

In Solution Explorer, right-click your project → **Add** → **Class...** → name it **NorthwindContext.cs**

```
using Microsoft.EntityFrameworkCore;

public class NorthwindContext : DbContext
{
    public DbSet<Customer> Customers { get; set; }

    protected override void OnConfiguring(DbContextOptionsBuilder options)
        =>
    options.UseSqlServer(@"Server=.\SQLEXPRESS;Database=Northwind;Trusted_Connection=True;TrustedServerCertificate=True;");
}
```

Create a new class that corresponds to column names in your database table
Here, since we want to read from the customer table we type:

```
public class Customer
{
    public string CustomerID { get; set; } = string.Empty;
    public string CompanyName { get; set; } = string.Empty;
    public string ContactName { get; set; } = string.Empty;
    public string? City { get; set; }
}
```

Note: Not all fields are considered

Read data

```
using System;
using System.Linq;

internal class Program
{
    static void Main(string[] args)
    {
        using var db = new NorthwindContext();

        var customers = db.Customers.ToList();

        foreach (var c in customers)
            Console.WriteLine($"{c.CustomerID,-5} {c.CompanyName,-40} {c.City}");
    }
}
```

Read data using LINQ

```
using System;
using System.Linq;

internal class Program
{
    static void Main(string[] args)
    {
        using var db = new NorthwindContext();

        var customers = db.Customers
            .OrderBy(c => c.CompanyName)
            .Take(10)
            .ToList();

        foreach (var c in customers)
            Console.WriteLine($"{c.CustomerID,-5} {c.CompanyName,-40} {c.City}");
    }
}
```

Please investigate other methods of Linq such as **Where** and **Select**

*** End ***